

How to use the a dishwasher



1. Remove large food residues
2. Place plates, cups, and cutlery in the racks
3. Open the detergent compartment and insert a tablet
4. Select a program
5. Press the **START** button



3

Programs

Intensive 70 °C	Suitable for heavily soiled dishes, pots, and pans
Eco *** 50 °C	Suitable for normal amount of soil. It's the most efficient program
Clean&Shine 65 °C	Daily washing programme for normally soiled dishes
Quick&Shine 60 °C	Daily washing programme for normally soiled dishes in the fastest way
Mini 35 °C	Suitable for lightly soiled daily dishes that are scraped or pre-cleaned