

How to use the coffee machine Ufesa CE7238 Cafetera

1. Fill the water tank



2. Add ground coffee to the filter.



3. Turn on the machine.



4. Turn the dial to the left to the cup icon.

